

FLIGHT OPERATION INSTRUCTION – 128

V1.0 Jul 07

Crewperson IHT Requirements

- The following procedures will apply for the volunteer crewpersons when a Class 1 Mission is paged. These procedures will make it easier for the duty pilot to keep the helicopter within its weight and balance limitations and also minimising the time spent away from Hastings for the duty volunteer crewperson during these missions.
- For all Class 1 missions outside of the Hawke's Bay region (Wellington, Auckland, Gisborne, and Hamilton) the duty volunteer crewperson is not to respond to the helipad. If the duty pilot wishes the duty crewperson to accompany a Class 1 Mission and the aircrafts weight and balance allows this, then the duty pilot will ring the duty crewperson to advise of their request. If contact cannot be made by phone then the duty pilot is to phone Central Com on 0800 262 266 or 0800 244 111 and get them to page **"Crew Required for Class 1 Mission immediately"**.
- During these out of region Class 1 Missions the duty crewperson will remain available for the standby helicopter should the need arise.
- All Class 1 missions to Wairoa are too be accompanied by the on duty crewperson providing the pilot in command is certain the entire flight can be undertaken with the aircraft remaining within its weight and balance limitations.

Brent Williams
Chief Pilot Rotary